9863 Public Edition Instructions

We are very glad that you chose this car navigation video and audio product, this manual will systematically introduce the basic functions, use skills and matters needing attention. Let new users quickly know, please read before use, thank you!

catalogue

1. Basic knowledge of the car and the machine.....2
.11 Basic operation of gesture recognition.....2
.21 Main interface and application interface.....2
.31 Wallpaper replacement.....2
.41 Main interfaceAdd an application shortcut.....3
1.5, Main interfaceDelete the application icon.....3
.61 Start-up LOGO setting.....3
2. Introduction of the main functions of the main interface.....4
.12 Navigation function.....4
2.2 Bluetooth function.....4
.32 Application interface.....8
.42. Radio function.....8
.52 Set the interface.....9
3. Introduction of the main functions of the application interface.....10
.13 Balancer.....10
3.2 Steering Wheel learning.....10
.33 File management.....11
.43 Touch screen assistant.....12
3.5 Music player.....13
3.6 Video player.....13
.73 Picture preview.....14
4. Relevant introduction of the Settings.....15
.14 Wireless settings.....15
.24 Device Settings.....16
.34 General settings.....16
.44 Factory Settings.....17
.54 Personal Settings.....17
.64 System Settings.....18

1. Basic knowledge of the car and the machine

1.1 Basic operation of gesture recognition

The gestures that machines can recognize are mainly divided into short press, long press, drag, sliding and other types. The same function has different results under different gestures, and the user operates the machine by touching the display.

1.2 Main interface and application interface

1. After the machine starts, jump to the main menu page by default, which mainly displays the shortcut ways to layout some common functions. Users can also adjust the layout of the page according to their personal preferences. This device has multiple page screens,

You can slide to the left or right to switch the interface, and click on the screen without the main screen The icon can be returned to the main

interface.

2. Click the icon on the main interface to enter the application interface.

.31 Wallpaper replacement

There are two ways to setup the wallpaper:

1. Press the wallpaper and dynamic wallpaper setting button in the main interface.

2. Set up the device to display the wallpaper, and choose the wallpaper according to your personal hobbies.



1.4 Main interface- -Add the application shortcut

Find the application icon to drag in the application interface. Press the icon for a few seconds and enter the drag state. At this time, the vehicle automatically switches from the application interface to the main menu, and the user can move the dragged icon to the main menu layout place.

1.5 Main interface- -Delete the application icon

When an application icon or widget is pressed on the main menu, the delete button pop up on the interface. If the user moves the long-pressed icon or widget to the delete button, it will enter the red delete state, and then you can easily recycle the icon or widget shortcut.

1.6 Start-up LOGO setting

1. Set the factory setting logo setting, and the user can choose the logo pattern that you want to specify.
2. Custom boot Logo: first, the set picture resolution should be greater than or equal to 1024x600, build a new mycar folder under the root directory of the SD card or USB, put the picture into the folder, insert the machine to enter the logo setting and slide to the last page to display the exit.

09:44
14
当前车标:
提示:
1.图片放在U盘或者SD卡的根目录下的mycar文件夹中
2.分辨率不小于1024X600

2. Introduction of the main functions of the main interface

The main interface is shown below:

.12 Navigation function

1. Click the navigation icon on the main interface, enter the map interface, click the icon to enter the search destination interface, and search the destination.

.22. Bluetooth function

Click the Bluetooth icon to enter the Bluetooth interface.



1. Bluetooth phone (click the icon to enter the Bluetooth phone interface)

The Bluetooth phone needs to be connected to the car before using the Bluetooth phone function.

1) Turn on the Bluetooth function of the mobile phone and the vehicle device respectively, and set the mobile phone to "visible to everyone".

2) Search for the Bluetooth device in the mobile phone, and then select for connection. At this time, you need to enter the matching password, usually: 0000. After entering the pairing, the display connection can be successful.3) The Bluetooth phone function can be used after the successful connection.

2. Blue, tooth music

Click the icon to enter the Bluetooth music interface, the car and the mobile phone Bluetooth connection is normal, can be through

The car Bluetooth plays the music in the phone, and can control the switch up and down.

3. Bluetooth synchronization of the mobile phone address book

Click the icon to enter the synchronous mobile phone address book interface, the car and machine synchronous mobile phone address book, the first to ensure that the mobile phone

The Bluetooth connection to the vehicle is normal. Here is the synchronization method:

1) Click the download icon to download the phone book, and the prompt box will pop up on the mobile phone to choose whether to allow the car and machine access

Mobile phone address book.

2) Wait for the car to pop up to complete the download prompt box, and then click the save button.

3) Click Search to find the contact person in the download phone book.

4) Click the Delete button to delete the contact person in the phone book.

4. Bluetooth call record

Click the icon to enter the call recording interface. All the call records during the Bluetooth connection between the car and the mobile phone will be displayed under this page. You can view the call, dial, hang up records, arranged from the nearest place according to the dialing time, and the records can also be deleted according to the call-in.



5. Bluetooth setup, and prepare the search interface

1. Click the icon to enter the device search interface, and then click the search button, Bluetooth will search for all nearby Bluetooth devices, and display them in the list, and find and select the Bluetooth device you want to connect in the list.

2. Click the connection button and send a connection request to the selected Bluetooth device. Enter a matching password in the selected Bluetooth device and the unconnected device. No connected icon. If the connection icon appears, the connection is successful.

3. Click to disconnect, to disconnect the device.

4. Click Clear the device to clear the device.

6. Bluetooth setting interface

The Bluetooth Settings page displays the name of the car Bluetooth machine and the matching password, and users can manually change the letters

breath. The automatic answer function is that when there is a phone call, the car and machine will automatically answer. All the Bluetooth information set by the user will be restored when the Bluetooth reset button is pressed.

.32 Application interface

Click the icon of the main interface to enter the application interface

.42. Radio function

Click the icon of the main interface to enter the radio interface, and users can set the following function points as required.

1. Click on the icon to switch the band, the radio band will cycle the switch between FM1, FM2 and FM3,

And the radio information on the six save information buttons in the curren and will also change. Due to the wide range of regions Broadcast band inconsistency, users can switch manually according to the local conditions.

2. Click on the icon to switch to the stereo sound.

3. Click the icon to search for the station. Press the button, the radio will search for the stations in all bands

come out.

4. Click the icon to switch between the far and close range.

5. Click the icon to save the radio station. The radio is divided into 5 bands, and each band can save 6 stations

information. Users can only long press any button in p1-p6 to save the current band frequency under the button. At the same time, you can also click the Save button, first click the address to be saved, then FM, click the Save button.

6. Click the icon edit button, pop up the edit box, click the cursor to edit the radio information (note: this item is not

Can be empty). After editing, press the keyboard button to complete. If you want to change the radio frequency, you can pass the left and right FM button, and click the save button after completion.

7. Click the icon to enter the radio receiver setting interface. In the radio setting interface, with FM sensitivity adjustment,

Of course, if the automatic stop sensitivity is open. In the radio setting interface set the FM sensitivity, or RDS switch, or after the area change, feel very messy, is not conducive for us to regulate the radio, we can click the default button, restore to the default setting.

.52 Set the interface

Click the setting icon to enter the setting interface

3. Introduction of the main functions of the application interface

3.1, Equilibrium and Equalizer

EQ 1. Enter the equalizer interface, users can click the button, sound field setting, surround sound, three-dimensional reinforcement and bass

Strengthen, sound filtering into the adjustment sound effect mode, the user can set the preset sound effect or set the sound effect by manually adjusting the setting value.



3.2 Steering Wheel learning

1. Steering wheel- -steering wheel button learning

For cars with steering wheel buttons, if the keys can be customized through the steering wheel. The steps are as follows:

Step 1, long press and hold down the button to learn on the steering wheel.

The second step, select the function button to be learned on the machine, and can not let go until a valid number (the number indicates the electrical resistance value of the key) appears under the key.

The third step: learn other keys according to the first two steps, and after learning, click the save button (the same key can only learn one function)

2. Steering wheel- -steering wheel button function

Power supply switch function

Mode key

Navigation function

Increase the sound, and the quantity function

Reduce the volume function

Silent function

Last song function

Next function

Fast back function

Fast forward function

Answer the phone function

Hang up the phone function

Save function

Clear function

3.3 Document management

File Manager interface

All files in the machine can be viewed and operated in the File Manager and the left side of the page has the file directory. If you need to copy or move a file, just select the file to be operated, and a row of operation buttons will appear at the bottom, select the file directory to be stored, and click the corresponding operation button.

3.4 Touch Screen Assistant

1. Show the button

The floating button in the touch screen assistant has many operational shortcuts, which can easily jump. If the user needs to display the floating button, click the touch screen assistant to enter the page and set the display button option.

2. Start up

After setting the floating button to display, make the floating button will automatically display each time by setting the boot start option, and there is no need to enter the touch screen assistant to set it each time. For video interfaces, navigation needs to hide floating buttons, which can be hidden when using car-related applications.

3. Button size adjustment

During the use of the touch screen assistant, you can set the button size to adjust the size of the floating button, and the user can set it according to your personal use habits.

09:06 14
触屏助手设置
显示按钮
开机启动
使用汽车相关的应用程序时
空调协议存在时使用空调功
按钮大小调节
大小调节

3.5 Music player

1. Music Player- -Music playlist

Enter the main interface of the music player through the main interface or the application icon of the application interface. If there is no play record, then jump to the list interface by default.

Song list button to display all songs in the internal storage and external storage device.

Folder list button, click this button to display the folder information for all of the songs in the vehicle and machine internal storage and external storage device.

Singer list button, click this button will classify the songs in the car with the singer information display.Album list button, click this button will classify the songs in the car with the album information display.

2. Music player-playback interface function brief introduction

List interface Select the songs to be played and click to jump to the play interface. The interface displays some basic information about the current playing song and the common control buttons. Users can set the corresponding button to achieve the corresponding effect, but also can drag the progress bar of the song to achieve the fast forward and fast back function.

3.6 Video player

1. Video player- -Video playback

Video player can identify all video resources from internal storage as well as in external storage, and supports playing a variety of common video formats such as 3gp, mp4, m4v, flv, f4v, mkv, webm, avi.Unique and simple operation interface, powerful decoding ability and support for HD video playback.

2. Video player- -Video list

In the video list interface, the user can view the corresponding video list by selecting the storage device type on the left.**(Note: The figure below shows the list of video videos in the current storage device, and on the right figure is the list of video folders in the current storage device.)**

3. Video playback interface and drawing in the drawing

Select the played video through the video list interface and jump to the video playback interface. The interface will display the title of the video and the playback progress, and you can realize the function of fast forward and fast back by dragging the progress bar. Touch the screen operation interface automatically hidden emerge, convenient to watch the video.

Click the drawing function button, the video playback interface will be reduced and superimposed on other application interfaces. And click the zoom in and full screen button in the upper right corner of the picture to choose the size of the video. In-picture features help users navigate navigation and other apps while watching videos.

3.7 Picture Preview

1. Picture browsing interface

Picture browsing function can browse all internal and external storage on the car, and can customize the wallpaper.

2. Figure, chip operation

Click any picture to enter the browsing mode, such as the left picture, the picture can zoom in and out, long press the screen can hide the function button operation, and support the picture moving with the finger, and gesture cut function.On the right is the key function of the image.

4. Relevant introduction of the Settings

.14 Wireless settings

1. Click the wireless Settings WLAN can enter the wifi interface, or the pull-down menu can long press the wifi button to enter the wifi interface, open the wifi, will display the searched nearby available wifi resources, select the available wifi name click connection.
2. Use traffic to view traffic usage, or to turn on and off the traffic saving program.
3. SIM information You can view the SIM card information inserted into the vehicle.
4. Among the more options, there are mobile network, network sharing of portable hot spots, flight mode, and VPN functions.This page allows users to connect to or to set up a wifi hotspot.

.24 Device Settings

1. Display: In the display options, users can set the screen brightness, wallpaper, and automatically enter the black screen function.

2. Sound: In the sound interface, the sound output effect of the machine can be set through the touch screen sound, LOU D, power amplifier switch, power, bass and equalizer options, and users can experience the effect according to the actual operation.

3. GPS: The GPS information displays the basic information of the machine positioning, and also supports the Beidou and GPS dual-module display.The automatic synchronization switch can control whether the time of the machine is synchronized with the positioned satellite time when the vehicle machine is positioned.

4. Storage: You can view the use of vehicle memory and external storage space.

5. Application: In the application options, users can view the use of the internal storage space in the application.Users need to uninstall or stop the installed external program, just find and click the program icon in the downloaded list, and click the required function button after pop the interface.

6. USB video output setting: access to the USB cable can output video.

.34 General settings

General settings can set some basic properties of the machine, and users can configure the functions according to their personal habits.

The functions are described as follows:

1. Open up with any button: click any button on the touch screen to start up
2. Brake setting: The video display is controlled by the hand brake state
3. Automatic access navigation: turn on the automatic access navigation function
4. Image time superposition: the image screen can be displayed after opening
5. Reverse mirror: The reversing image is displayed mirrored
6. Reverse mute: block other sound output when reversing
7. Reverse sound: control the sound of the reversing background
8. Backlight control: there are time control and small light control
9. Default volume switch: control the boot default volume setting
10. Booon default volume: Set the default volume value
11. GPS remix: control the background sound output during the navigation signal report
12. Mix ratio: control the background sound size during navigation sound reporting
13. Lantern setting: control the color of the key light on the screen
14. Steering wheel Settings: Enter the steering wheel learning interface
15. Navigation application Settings: Set the navigation map called
16. Map copy: Copy the map packet is installed at the target location

.44 Factory Settings

Factory settings can be configured for the function of the machine, and the correct matching password is required to enter the normal operation of the machine.

.54 Personal Settings

1. Location information use right: In the location information use right option, the GPS satellite positioning can be set up to obtain your current location information.The GPS satellite positioning function needs to be kept regularly open to ensure the normal use of the navigation function.
2. Security: You can view the device management application, fixed screen on and off and other functions.
3. Language and input method: You can switch languages and add languages.
4. Backup and reset: the factory settings can be restored. In order to ensure the normal operation of the machine, users are not recommended to change the settings under non-special circumstances.
5. Break A C C delay power failure: the delay time of power failure can be set.

.64 System Settings

1. Date and time: Set the system time, which generally provides a time mode for automatic network acquisition.
2. About the car and machine: it mainly displays the basic information of the applications, systems and other software in the machine.
3. Set different information: you can view the IMEI number of the SIM card slot.

Help- -FAQs

1. Mobile Bluetooth and car Bluetooth matching connection?

If the Bluetooth connection is not available, you can turn off the Bluetooth of the mobile phone first, and then open and search again before connecting. If not again, you can click the reset of the Bluetooth setting, and then pair it up after a few seconds.

2. Bluetooth music without a sound?

Make sure that the paired cell phone has a volume output.

3. Did click download the phone book?

After bluetooth connection, the phone book click download, the phone will receive a request from the download contact, confirm and allow the download request to download.

4. Not updated after the Bluetooth name is set?

After the Bluetooth name is set, if it is not updated immediately, please disconnect the Bluetooth and then click on the

matching connection.5. No data update when plugged in on the SD card or USB in the first time?

Users after plug in the storage device, the music player will detect and scan the data, if the storage data is large, may need a little time to update (a few seconds-1 minutes), if there is no update, please make sure that the storage device is mounted (see the file browser, see if there is a corresponding storage directory, if no directory, please plug the card, or check the hardware).

6. The name of the song file is scrambled?

The name of the song is not a file name, but the song itself is encoded incorrectly if it is neither in a common format, nor in the native language.